FOR EVERYONE EVERYWHERE, EVERY PLACE, EVERY HOME

Rinse Aid



Rinse Aid has been specially formulated to eliminate water spotting on glassware, crockery and cutlery. It is also designed to help disperse the rinse water to ensure the rapid drying of dishes and utensils. This product is suitable for all water conditions, simple and safe to use.

Rinse Aid has an advanced formula that eliminates the possibility of scale formation within the washing machine ensuring an excellent performance. Rinse Aid is ideally suited for use in all commercial and automatic ware-washing machines.

- FRESH WORKS IN HARD OR SOFT WATER
- LEAVES GLASSES SPARKLING & STREAK FREE
- ECONOMICAL FORMULA
- PHOSPHATE FREE
- BIODEGRADABLE SURFACTANTS
- SAFE FOR FOOD PROCESSING AREAS & SEPTIC TANKS WHEN USED ACCORDING TO DIRECTIONS PROVIDED

Directions for use:

Machine with no Automatic Rinse & Dispenser: Add $\frac{1}{2}$ - $\frac{1}{4}$ teaspoon to the final rinse.

Machine with Automatic Rinse & Dispenser: Refer to your machine instruction booklet. Check dispenser regularly.

Safety Information: Please consult Safety Data Sheet prior to use.

www.sanitiseandclean.com.au

Phone: 02 8377 3499 | SMS your order: 0488 707 077 14A Williamson Rd, Ingleburn NSW 2565 Email: orders@sanitiseandclean.com.au ABN 97 630 993 010



Packaging:	5 litres, 20 litres
Appearance:	Blue thin liquid
Solubility (Water):	Soluble
Ph:	6.5 - 7.5
Specific Gravity:	1.0 - 1.02
Fragrance:	None
Use:	Domestic & Industrial
Category:	Kitchen



Sanitising & Cleaning

Solutions